

<b>ACER</b>			
DVD DUAL 4XMax	DVD RW 4XMax	DVD RW 8XMax	

<b>Actima</b>			
ARW4420	ARW4420S	CD-RW CRW4012A	DVD+RW ADRW-H00P

<b>ALN</b>			
DVD+/-RW AL1300A			

<b>Aopen</b>			
12X10X32 CD-RW A/P	16X10X32 CD-RW	16X48X24X48	2.4X2.4X8 121032
20X10X40 CD-RW	24X10X40 CD-RW	40X12X50 CD-RW	48X12X50 CD-RW
48X24X52 CD-RW	4X4X8 241640	52X24X52 CD-RW	52X32CD-R/RW
52X32COMBO	52X32X52 CD-RW	8X8 DVD Dual AAG	8X8 DVD Dual AAN
8X8 DVD Dual APP	CD-RW CRW1232 A/PRO	CD-RW CRW1632	CD-RW CRW2040
CD-RW CRW2440	CD-RW CRW3248	CD-RW CRW4050	CD-RW CRW4850
CD-RW CRW4852	CD-RW CRW5224	CD-RW CRW5232	COM4824/AAH
COM5232/AAH PRO	CRW5232/AAO PRO	CRW9420	CRW9420S
DRW8800/APP	DVRW2412PRO	DVRW4416PRO	

<b>ASUS</b>			
CRW-4816A	CRW-5224A	SCB-1608	SCB-2408
DRW-24F1ST a	BW-16D1HT	BW-12B1ST a	SBW-06D2X-U
DRW-24D5MT	DRW-24D3ST	SDRW-08U7M-U	

<b>ATAPI</b>			
CD R DH52R1P	CD-RW 40X12	CD-RW 48X16	CD-RW 48X24
CD-RW 48XMAX	CD-RW 52X24	CD-RW 52X32	CD-RW 52XMAX
DVD A DH16AAS	DVD DD 2X16X4X16	DVD DUAL 4XMax	DVD RW 4XMax
DVD RW 8XMax	DVD RW DD0201	DVD RW DD0203	DVD RW DD0401
DVD RW TDD0201	iHAS122	iHAS122 8	iHAS122 W
iHAS124 Y	iHAS324 B	iHAS524 B	iHBS112 2
iHBS212 2	iHES208 2	iHAS124 B	iHBS312 2
BD E DH12E3SH	iHAS324 F	iHES106 2	

<b>ATK</b>			
DVD RW DD0201	DVD RW DD0203	DVD RW DD0401	DVD RW TDD0201

<b>BENQ</b>			
CDRW 5232X			

<b>BTC</b>			
BCE1610IM	BCE3212IM	BCE4012IM	BCE4816IM
BCE5224IM	BCE5224SO	BCE5232IM	BCE5232SO
BCO1612IM	BCO4016IM		

<b>CARAVELL</b>			
CDR-N820S	CRW-8220S		

<b>CD-RW</b>			
CDR-4048S	CDR-4048SD	CDR-4048W	CDR-4848S
CDR-5G48	CDR-5S48	CDR-5W48	CDR-6K48
CDR-6S48	CDR-6S52	CDR-7K52	CDR-7S52
MAR-401248S	MAR-401248SD	MAR-401248W	SMART CLONE48
SMART CLONE52			

<b>CD-R/RW</b>			
52X24X52X			

<b>CDWriter</b>			
IDE1610	IDE5224	IDE5224SO	IDE5232
IDE5232SO			

<b>CENDYNE</b>			
522452AL			

<b>CNBridge</b>			
CBCO1K-48X	CBRW6K-52X	CBRW6S-48X	CBRW6S-52X
CBRW7K-52X	CBRW7S-52X		

<b>COMBI</b>			
COB-1K4816	RW16x10/DVD	RW16x12/DVD	RW16x8/DVD

<b>COMBO</b>			
BCO5232IM	COB-1K4816	IDE1612CO	IDE4016CO
IDE5216CO	IDE5232CO		

<b>CREATIVE</b>			
COMBO CBA820E	RW4810E	RW4811E	RW6424E

<b>CyberDrv</b>			
CW089D CD-R/RW	CW099D CD-R/RW		

<b>CYQVE</b>			
CQ1232	CQ7125	CQ8060A	

<b>Delta</b>			
OIP-RW2004	OME-W141		

<b>DGMaster</b>			
DGM-241040	DGM-321240	DGM-401248	DGM-481248
DGM-482448			

<b>DVDRW</b>			
DRW-2S81	IDE1108		

<b>EMC</b>			
CD-R/RW 52X24X52			

<b>FREECOM</b>			
DVD+/-RW16B6	DVD+/-RW16B7	DVD+/-RW16B8	DVD+/-RW16B9
DVD+/-RW4B	DVD+/-RW8B	DVD+/-RW8B9	

<b>GENERIC</b>			
CRD-RW1	CRD-RW1N	DVD DUAL 4XMax	DVD RW 4XMax
DVD RW 8XMax	DVD-RAM MLT01	DVD-RAM MLT02	DVD-RAM MLT03
DVD-RAM MLT04	DVD-RAM MLT05	DVD-RAM MLT06	DVD-RAM MLT07
FREECOM32A			

<b>GENERICP</b>			
UJ-820P	UJ-822P	UJ-830P	UJ-831P

<b>HL-DT-ST</b>			
BDDVDRW CH12NS28	BDDVDRW CT10L	BDDVDRW CT10N	BD-RE BH08NS20
BD-RE BH10NS30	BD-RE BH10NS38	BD-RE BH12NS38	BD-RE BH14NS48
BD-RE BH16NS48	BD-RE BH20L	BD-RE BH20N	BD-RE BP40NS20N
BD-RE BT10L	BD-RE BT10N	BD-RE BT10N	BD-RE BT20N
BD-RE GGW-H20L	BD-RE GGW-H20N	CD-RW GCE-8160B	CD-RW GCE-8480B
CD-RW GCE-8481B	CD-RW GCE-8523B	CD-RW GCE-8526BN	CDRW/DVD GCC4244
DVD RAM GSA-T10N	DVD+-RAM GSA-T40N	DVD+-RW GSA-H73N	DVD+-RW GSA-U20N
DVD+-RW GT10N	DVD+-RW GU10N	DVD+-RW GU40N	DVDRAM GH20NS10
DVD-RAM GH22NP2	DVD-RAM GH22NS30	DVDRAM GH22NS40	DVDRAM GH22NS50
DVDRAM GH22NS70	DVDRAM GH24NS50	DVDRAM GH24NS70	DVDRAM GH24NS72
DVDRAM GH24NS90	DVDRAM GH24NS95	DVD-RAM GH40L	DVD-RAM GH40N
DVDRAM GH60L	DVDRAM GH60N	DVD-RAM GH70N	DVDRAM GH80N
DVD-RAM GH80N	DVD-RAM GH82N	DVDRAM GMA-4020B	DVDRAM GMA-4080N
DVDRAM GP30NB30	DVDRAM GS30N	DVDRAM GSA-4040B	DVDRAM GSA-4080B
DVDRAM GSA-4080N	DVDRAM GSA-4081B	DVDRAM GSA-4082B	DVDRAM GSA-4082N
DVDRAM GSA-4120B	DVDRAM GSA-4160B	DVDRAM GSA-4163B	DVDRAM GSA-4163B
DVDRAM GSA-4165B	DVDRAM GSA-4167B	DVDRAM GSA-4168B	DVDRAM GSA-H10A
DVDRAM GSA-H10N	DVDRAM GSA-H12L	DVDRAM GSA-H12N	DVD-RAM GSA-H40L
DVD-RAM GSA-H40N	DVDRAM GSA-H42L	DVDRAM GSA-H42N	DVDRAM GSA-H44N
DVDRAM GSA-H60L	DVDRAM GSA-H62N	DVD-RAM GSA-H70N	DVDRAM GSA-T20N
DVDRAM GSA-T40F	DVDRAM GSA-T40L	DVDRAM GSA-T40N	DVDRAM GSA-T50F
DVDRAM GSA-T50L	DVDRAM GSA-T50N	DVDRAM GSA-U10N	DVDRAM GSA-U20F
DVDRAM GSA-U20N	DVDRAM GT10N	DVDRAM GT20F	DVDRAM GT20L
DVDRAM GT20N	DVDRAM GT30F	DVDRAM GT30L	DVDRAM GT30N
DVDRAM GT30N	DVDRAM GT40N	DVDRAM GT50N	DVDRAM GT60N
DVDRAM GT80N	DVDRAM GU10F	DVDRAM GU10N	DVDRAM GU40N
DVDRAM GH10N	DVDRAM_GSA-4080N	DVDRAM_GSA-4082N	DVDRAM_GSA-4165B
DVDRAM_GSA-4167B	DVDRAM_GSA-H10A	DVDRAM_GSA-H10N	DVDRAM_GSA-H60N
DVDRAM_GSA-T50N	DVDRW_GS31N	DVD-RW_GH80N	DVDRWBCT10N
RW/DVD_GCC-4240N	RW/DVD_GCC-4241N	RW/DVD_GCC-4244N	RW/DVD_GCC-4320B
RW/DVD_GCC-4480B	RW/DVD_GCC-4481B	RW/DVD_GCC-4482B	RW/DVD_GCC-4483B
RW/DVD_GCC-4484B	RW/DVD_GCC-4520B	RW/DVD_GCC-4521B	RW/DVD_GCC-4522B
RW/DVD_GCC-4241N	RW/DVD_GCC-4244N	RW/DVD_GCC-H20N	RW/DVD_GCC-H22N
RW/DVD_GCC-H32N	RW/DVD_GCC-T10N	RW/DVD_GCC-T20N	DVD+-RW_GHA2N
DVD-RAM_GHA2N	DVDRAM_GH24NSB0	BD-RE_WH14NS40	DVD-RAM_GHBN
DVDRAM_GTA0N	BD-RE_WH16NS40	DVDRAM_GH24NSC0	DVDRAM_GUB0N
DVDRAM_GP60NB50	DVD+-RW_GU90N	DVDRAM_GTC0N	DVDRAM_GU61N
DVDRAM_GH24NSD1	DVDRAM_GUD0N	BD-RE_BH16NS58	DVDRAM_GUD1N
BD-RE_BU20N	BD-RE_BH14NS58	DVDRAM_GH22NS90	DVDRAM_GTB0N
DVDRAM_GA10N	BD-RE_WH16NS48	DVDRAM_GP65NB70	DVDRAM_GP50NB40
DVDRAM_GP10NB20	DVDRAM_GP65NB60	DVDRAM_GP70NS50	BD-RE_BU40N

<b>HP</b>			
CDDVDW SH-216ALN	CDDVDW SH-216BB	CDDVDW TS-H653R	CDDVDW TS-H653T
CDDVDW TS-H653TN	CDDVDW TS-L633R	CD-Writer cd12d	CD-Writer cd12n
CD-Writer cd16e	CD-Writer cd16n	CD-Writer cd16r	CD-Writer cd24p
CD-Writer cd4f	CD-Writer+ 8200	CD-Writer+ 8290	CD-Writer+ 9100
CD-Writer+ 9100c	CD-Writer+ 9200	CD-Writer+ 9500	CD-Writer+ 9500b
CD-Writer+ 9600	CD-Writer+M820	DVD A DH16AAL	DVD A DH16ABLH
DVD A DH16ABSH	DVD A DH16ACSH	DVD Writer 100j	DVD Writer 200j
DVD Writer 300n	DVD Writer 400n	DVD Writer 420n	DVD Writer 520n
DVD-RAM GH60L	DVD-RAM GH80N	DVD-RAM GH82N	DVDRAM GS30N
DVDRAM GT30L	DVDRAM GU40N	DVD RW AD-7250H5	DVD RW AD-7251H5
DVD RW AD-7561S	DVD RW AD-7581S	DVD RW AD-7711H	DVD RW AD-7721H
DV-W28S-W	DVD-RAM_GHA3N	CDDVDW SH-216DB	DVD A DH16AESH
DVD A_DS8A9SH	DVD-RAM_GHBN	CDDVDW SN-208FB	CDDVDW SN-208DB
DVDRAM_GTA0N	CDDVDW_SU-208CB	CDDVDW SN-208BB	CDDVDW_SU-208FB
DVDRAM_GTB0N	DVD A_DS8ACSH	BD-RE_BU20N	DVDRAM_GTC0N
DVDRW_DU8A6SH	BD-RE_BH20L	BD-RE_BH20N	

<b>HP HLDS</b>			
DVDRW GUDON			

<b>HP TSST</b>			
DVDRW SU-208HB			

<b>IBM</b>			
CDRW-USB2			

<b>IDE-GD</b>			
R/RW 12x10	R/RW 12x8	R/RW 12x8x32	R/RW 4x4x24
R/RW 4x4x32	R/RW 8x4x32		

<b>IDE-DVD</b>			
DVDRW6001	DVDRW6002		

<b>IMATION</b>			
IMW040420			

<b>IO DATA</b>			
CDRWD-RX1210J	CDRW-SX64	CRWD-RX20J	

<b>IOMEGA</b>			
CDRW27648INT-B	CDRW55292EXT3-B	CDRW55292INT-B	CDRW55296INT-B
CDRW5529DEXT1-B	CDRW5529FEXT1-B	CDRW64892EXT3-B	CDRW64896INT-B
CDRW86592EXT3-B	CDRW9600INT	DVDRW4216E2D-A	DVDRW4216IND-A
DVDRW4216INP-A	ZIPCD 4x650	ZIPCD 650 USB	ZIPCD1024INT-A
ZIPCD3840INT-A			

<b>JLMS</b>			
COMBO LSC-24081	COMBO LSC-24081M	COMBO LSC-24081S	LTC-48161K

<b>JVC</b>			
XR-W4082	RW4224	XR-RW2224	XR-RW4424
XR-W4080S JVC製品型番: ・XR-S4224W ・XR-K4224Wのみ対応			

<b>LACIE</b>			
CD-BP12432S	CDBP-241040A	CDBP-321040A	CDBP-401240A
CDR-RW12432S	CDRW-BOOSTER		

<b>LG</b>			
CED-8042B	CED-8080B	CED-8083B	CED-8120B

<b>LITE-ON</b>			
CD-RW SOHR-5238S	CD-RW SOHR-5239S	COMBO LTC-48161H	COMBO SOHC-4832K
COMBO SOHC-4836K	COMBO SOHC-5232K	COMBO SOHC-5235K	COMBO SOHC-5236K
DVDRW SOHW-812S	LTR-0841	LTR-12101B	LTR-16102B
LTR-24102B	LTR-32102H	LTR-32102S	LTR-32123H
LTR-32123S	LTR-3248MH	LTR-40125S	LTR-40125W
LTR-40126H	LTR-40126S	LTR-48125G	LTR-48125W
LTR-48126S	LTR-48246K	LTR-48246S	LTR-52246K
LTR-52246S	LTR-52326K	LTR-52326S	LTR-52327K
LTR-52327S	LXR-32122	LXR-32122A	LXR-32122B
LXR-32122C	LXR-40122	LXR-40122A	LXR-40122B
LXR-40122C			

<b>Logitec</b>			
LDR-PUA8U2S	LDR		

<b>MAD DOG</b>			
MD-16X2DVD9-8X	MD-16X3DVD9-8X	MD-16XDVD9	MD-16XDVD9A2
MD-16XDVD9A4	MD-8XDVD9-PM		

<b>MAG</b>			
CD-R/RW 52X24X52			

<b>MATSHITA (Panasonic)</b>			
BD-CMB UJ140AS	BD-CMB UJ141ES	BD-CMB UJ152	BD-MLT LF-MB121
BD-MLT LF-PB371	BD-MLT SW-5582	BD-MLT SW-5582A	BD-MLT SW-5583
BD-MLT SW-5584	BD-MLT UJ-210S	BD-MLT UJ-220S	BD-MLT UJ-225S
BD-MLT UJ230AS	BD-MLT UJ240AF	BD-MLT UJ260	BD-MLT UJ260AF
BD-MLT UJ262	BD-MLT UJ265	BD-MLT UJ272	CD-R CW7501
CD-R CW7502	CD-R CW7503	CDRCB01	CDRCB02
CDRCB03	CDRCB04	CDRCB05	CDRCB06
CDRRW01	CDRRW02	CDRRW03	CDRRW04
CDRRW05	CDRRW06	CDRRW07	CDRRW09
CDRRW10	CD-RW CW7121	CD-RW CW7585	CD-RW CW7586
CD-RW CW-8122	CD-RW CW-8123	CD-RW CW-8124	CD-RW CW8571
CD-RW CW8572	DVD/CDRW UJDA770	DVD/CDRW UJDA775	DVD+-RW UJ-822D
DVD+-RW UJ-857G	DVD+-RW UJ8C1	DVD+-RW UJ8D1	DVD-R UJ-857E
DVD-R UJ-85J	DVD-R UJ-825	DVD-R UJ-835	DVD-R UJ-845
DVD-R UJ-846	DVD-R UJ-857	DVD-R UJ-857D	DVD-RAM LF-D310
DVD-RAM LF-D521	DVD-RAM LF-M721	DVD-RAM LF-M760	DVD-RAM LF-M821
DVD-RAM LF-M860	DVD-RAM LF-P567	DVD-RAM LF-P667	DVD-RAM LF-P767
DVD-RAM LF-P867	DVD-RAM LF-P967	DVD-RAM LF-P968	DVD-RAM SW-9501
DVD-RAM SW-9571	DVD-RAM SW-9572	DVD-RAM SW-9573	DVD-RAM SW-9573S
DVD-RAM SW-9574	DVD-RAM SW-9574A	DVD-RAM SW-9574S	DVD-RAM SW-9576S
DVD-RAM SW-9581	DVD-RAM SW-9581N	DVD-RAM SW-9582	DVD-RAM SW-9582N
DVD-RAM SW-9583	DVD-RAM SW-9583A	DVD-RAM SW-9583S	DVD-RAM SW-9584
DVD-RAM SW-9584A	DVD-RAM SW-9585	DVD-RAM SW-9585A	DVD-RAM SW-9585S
DVD-RAM SW-9586	DVD-RAM SW-9587	DVD-RAM SW-9587A	DVD-RAM SW-9587S
DVD-RAM SW-9588	DVD-RAM SW-9590	DVD-RAM SW-9590A	DVD-RAM UJ-810
DVD-RAM UJ-811	DVD-RAM UJ-812	DVD-RAM UJ-813	DVD-RAM UJ-815
DVD-RAM UJ-820	DVD-RAM UJ-820c	DVD-RAM UJ-820S	DVD-RAM UJ-822
DVD-RAM UJ-822c	DVD-RAM UJ-822S	DVD-RAM UJ-822Sa	DVD-RAM UJ-822Se
DVD-RAM UJ-823S	DVD-RAM UJ-825	DVD-RAM UJ-825S	DVD-RAM UJ-830
DVD-RAM UJ-830c	DVD-RAM UJ-830cc	DVD-RAM UJ-830S	DVD-RAM UJ-830Sa
DVD-RAM UJ-830Se	DVD-RAM UJ-831S	DVD-RAM UJ-831Sa	DVD-RAM UJ-831Se
DVD-RAM UJ-832S	DVD-RAM UJ-833S	DVD-RAM UJ-835	DVD-RAM UJ-835A
DVD-RAM UJ-835S	DVD-RAM UJ-840S	DVD-RAM UJ-840Se	DVD-RAM UJ-841S
DVD-RAM UJ-842S	DVD-RAM UJ-844S	DVD-RAM UJ-845A	DVD-RAM UJ-845S
DVD-RAM UJ-846	DVD-RAM UJ-846A	DVD-RAM UJ-846S	DVD-RAM UJ-850S
DVD-RAM UJ-852c	DVD-RAM UJ-852S	DVD-RAM UJ-857G	DVD-RAM UJ-85JA
DVD-RAM UJ-85JS	DVD-RAM UJ862AS	DVD-RAM UJ862PS	DVD-RAM UJ867AS
DVD-RAM UJ867PS	DVD-RAM UJ869AS	DVD-RAM UJ870AS	DVD-RAM UJ870BJ
DVD-RAM UJ870PC	DVD-RAM UJ870PS	DVD-RAM UJ870QJ	DVD-RAM UJ875PS
DVD-RAM UJ-875S	DVD-RAM UJ880AS	DVD-RAM UJ890AS	DVD-RAM UJ892AS
DVD-RAM UJ892ES	DVD-RAM UJ8A0AS	DVD-RAM UJ8A2ES	DVD-RAM UJ8B0
DVD-RAM UJ8B1AS	DVD-RAM UJ8C0	DVD-RAM UJ8C2	DVD-RAM UJ8E2
DVD-RAM VW-BN1-1	LKM-KB23	SW-9573/SW-9583	SW-9573D/SW-9583D
SW-9584D	UJ-810	UJ-811	UJ-812
UJ-813	UJ-820	UJ-820D	UJ-822
UJ-822D	UJ-822Da	UJ-825	UJ-825D
UJ-830	UJ-830D	UJ-830Da	UJ-831D
UJ-831Da	UJ-832D DVD/CDRW	UJ-835	UJ-835D
UJ-840D	UJ-845D	UJ-857F	UJDA310
UJDA320	UJDA330	UJDA340	UJDA360
UJDA710	UJDA720	UJDA730	UJDA740
UJDA745	UJDA747	UJDA750	UJDA750cDVD/CDRW
UJDA750FDVD/CDRW	UJDA755	UJDA755cDVD/CDRW	UJDA755yDVD/CDRW
UJDA755zDVD/CDRW	UJDA757	UJDA760	UJDA760aDVD/CDRW
UJDA760cDVD/CDRW	UJDA760eDVD/CDRW	UJDA765 DVD/CDRW	UJDA765aDVD/CDRW
UJDA765cDVD/CDRW	UJDA769	UJDA770	UJDA770 DVD/CDRW
UJDA770 DVD/CDRW	UJDA775 DVD/CDRW	UJDA780 DVD/CDRW	UJDA782 DVD/CDRW
UJDD410	UJDD420	DVD-RAM SW820	DVD-RAM UJ8E0
DVD+-RW SW830	DVD-RAM UJ8E1	BD-CMB UJ162	DVD-RAM UJ-842 z
DVD-RAM UJ8G2	DVD-RAM UJ8E2 S	BD-RE UJ272	BD-MLT UJ240AS
BD-CMB UJ135AS	DVD-RAM UJ8C5	DVD-RAM UJ8A7AS	

<b>Maxell</b>			
MCD-RW4812-48	MCD-RW4824-48		

<b>MELCO</b>			
CDRW-S4224			

<b>Memorex</b>			
48MAXX 1248AJ	48MAXX 2448AJ	52MAXX 2452AJ	52MAXX 3252AJ
CD-RW 12432S	CDRW-4420	CDRW-4420s	CD-RW8220S
DVD+/-RW True8Xn	DVD+R/RW 2.4X8AA	DVD16+/-DL4RWnD2	TwelveMAXX 1032A/P

<b>Mitsubishi</b>			
CDRW4420	CDRW4420a		

<b>MITSUMI</b>			
CR-2802TE	CR-4802TE	CR-4804TE	CR-4805TE
CR-4808TE	CR-48X5TE	CR-48X8TE	CR-48X9TE
CR-48XATE	CR-48XCTE	CR-48XETE	CR-48XGTE
DR-6800TE	DW-7801TE	DW-7802TE	

<b>MSI</b>			
CD-RW CR48	CD-RW CR52		

<b>NEC</b>			
CB-2100A	CB-2100A_NE	CD-RW NR-7800A	CD-RW NR-9400A
CDRW/DVD CB1100A	DVD_RW ND-1200A	DVD_RW ND-1200AD	DVD_RW ND-1300A
DVD_RW ND-2300A	DVD_RW ND-2500A	DVD_RW ND-2500A2	DVD_RW ND-2510A
DVD_RW ND-3500A	DVD_RW ND-3500AD	DVD_RW ND-3500AG	DVD_RW ND-3520A
DVD_RW ND-3520AW	DVD_RW ND-3521A	DVD_RW ND-3530A	DVD_RW ND-3540A
DVD_RW ND-3540B	DVD_RW ND-3550A	DVD_RW ND-3551A	DVD_RW ND-3570A
DVD_RW ND-3571A	DVD_RW ND-4550A	DVD_RW ND-4551A	DVD_RW ND-4570A
DVD_RW ND-4571A	DVD_RW ND-5500A	DVD_RW ND-6650A	DVD_RW ND-7550A
DVD_RW ND-7551A	DVD_RW ND-7551B	DVD+RW ND-1000A	DVD+RW ND-1100A
DVD+RW ND-2100A	DVD+RW ND-2100AD	DVD+-RW ND-2510A	DVD+RW ND-3100A
DVD+RW ND-3100AD	DVD+-RW ND-3450A	DVD+-RW ND-3530A	DVD+RW ND-5100A
DVD+RW ND-6050A	DVD+RW ND-6100A	DVD+-RW ND-6450A	DVD+-RW ND-6500A
DVD+-RW ND-6650A	DVD-RW ND-1300M	NR-7500A	NR-7700A
NR-7800A	NR-7800B	NR-7900A	NR-8400A
NR-8500A	NR-9100A	NR-9200A	NR-9300A
NR-9300A_S	ODX658		

<b>Norcent</b>			
RWJ-481S	RWJ-482S	RWJ-483S	

<b>OLYMPUS</b>			
S-DVD-100			

<b>OPTI</b>			
DVD DUAL 4XMax	DVD RW 4XMax	DVD RW 8XMax	

<b>Optiarc</b>			
BD ROM BC-5540H	BD ROM BC-5600S	BD ROM BC-5650H	BD RW BD-5300S
BD RW BD-5730S	CD-RW CRX880A	CDRWDVD CRX890A	CDRWDVD CRX890S
DVD RW AD-5170A	DVD RW AD-5170S	DVD RW AD-5173A	DVD RW AD-5173S
DVD RW AD-5200A	DVD RW AD-5200S	DVD RW AD-5201S	DVD RW AD-5203A
DVD RW AD-5203S	DVD RW AD-5230H	DVD RW AD-5230S	DVD RW AD-5240S
DVD RW AD-5250H	DVD RW AD-5260S	DVD RW AD-5540A	DVD RW AD-5540B
DVD RW AD-5543A	DVD RW AD-5590A	DVD RW AD-5590S	DVD RW AD-5593A
DVD RW AD-5593S	DVD RW AD-5630A	DVD RW AD-5633A	DVD RW AD-5700H
DVD RW AD-5700S	DVD RW AD-5910A	DVD RW AD-5913A	DVD RW AD-7170A
DVD RW AD-7170S	DVD RW AD-7173A	DVD RW AD-7173S	DVD RW AD-7200A
DVD RW AD-7200S	DVD RW AD-7201S	DVD RW AD-7201S5	DVD RW AD-7201S6
DVD RW AD-7203A	DVD RW AD-7203S	DVD RW AD-7230H	DVD RW AD-7230S
DVD RW AD-7231H	DVD RW AD-7231S	DVD RW AD-7233H	DVD RW AD-7233S
DVD RW AD-7240S	DVD RW AD-7241S	DVD RW AD-7243S	DVD RW AD-7250H
DVD RW AD-7251H	DVD RW AD-7253H	DVD RW AD-7260S	DVD RW AD-7261S
DVD RW AD-7263S	DVD RW AD-7280S	DVD RW AD-7290H	DVD RW AD-7530A
DVD RW AD-7530B	DVD RW AD-7540A	DVD RW AD-7543A	DVD RW AD-7543B
DVD RW AD-7543C	DVD RW AD-7560A	DVD RW AD-7560S	DVD RW AD-7561A
DVD RW AD-7561S	DVD RW AD-7563A	DVD RW AD-7580A	DVD RW AD-7580S
DVD RW AD-7581A	DVD RW AD-7581S	DVD RW AD-7585H	DVD RW AD-7590A
DVD RW AD-7590B	DVD RW AD-7590S	DVD RW AD-7590T	DVD RW AD-7593A
DVD RW AD-7593B	DVD RW AD-7593S	DVD RW AD-7593T	DVD RW AD-7630A
DVD RW AD-7633A	DVD RW AD-7640A	DVD RW AD-7640S	DVD RW AD-7670S
DVD RW AD-7690H	DVD RW AD-7700H	DVD RW AD-7700S	DVD RW AD-7700T
DVD RW AD-7703H	DVD RW AD-7703S	DVD RW AD-7710H	DVD RW AD-7711H
DVD RW AD-7713H	DVD RW AD-7717H	DVD RW AD-7720H	DVD RW AD-7721H
DVD RW AD-7723H	DVD RW AD-7913A	DVD RW AD-7920S	DVD RW AD-7923S
DVD+-RW AD-5170S	DVD+-RW AD-5540A	DVD+-RW AD-7200S	DVD+-RW AD-7230S
DVD+-RW AD-7250H	DVD+-RW AD-7560S	DVD+-RW AD-7585H	DVD+-RW AD-7640A
DVD+-RW AD-7640S	DVD+-RW AD-7700S	DVD-RAM AD-7200A	RW/DVD_GCC-H22N
DVD RW AD-5280S			

<b>OPTORITE</b>			
DVD RW DD0201	DVD RW DD0203	DVD RW DD0401	DVD RW TDD0201

PHILIPS			
16840 CDRW	228CDRW	241240 CDRW	321240 CDRW
401240 CDRW	401248 CDRW	428CDRW	4424CDRW
8432CDRW	CDD4201 CD-R/RW	CDD4801	CDD4851 CD-R/RW
CDD5101	CDD7052	CDRW2010	CDRW3210S
CDRW3212S	CDRW4012P	CDRW48P	CDRWDVD1610
CDRWDVD1612	DVD+RW-D01	DVD+RW-D02	DVD+RW-D28
DVD6001	DVD6002	DVD8631	DVDRW1208
DVDRW228	DVDRW416N	PCRW1208	PCRW1208JR
PCRW1208MR	PCRW1208UE	PCRW404	PCRW406
PCRW804	ReWritable-2 × 2 × 6	SDVD6004	

PIONEER			
BD-ROM BDC-US01	BD-RW BDR-203	BD-RW BDR-205	BD-RW BDR-206
BD-RW BDR-206M	BD-RW BDR-207M	BD-RW BDR-208	BD-RW BDR-208M
BD-RW BDR-PR1	BD-RW BDR-TD05	BD-RW BDR-TS04	BD-RW BDR-UD02
BD-RW BDR-XU02	DCR-111	DVD-RW DVR-115	DVD-RW DVR-115D
DVD-RW DVR-115L	DVD-RW DVR-116	DVD-RW DVR-116D	DVD-RW DVR-116L
DVD-RW DVR-117	DVD-RW DVR-117D	DVD-RW DVR-117L	DVD-RW DVR-215
DVD-RW DVR-215D	DVD-RW DVR-215L	DVD-RW DVR-216	DVD-RW DVR-216D
DVD-RW DVR-216L	DVD-RW DVR-217	DVD-RW DVR-217D	DVD-RW DVR-217L
DVD-RW DVR-219L	DVD-RW DVRTD09	DVD-RW DVR-XD09	DVD-RW DVR-XD10
DVR-103	DVR-104	DVR-105	DVR-106D
DVR-107D	DVR-108	DVR-109	DVR-110
DVR-110D	DVR-111	DVR-111D	DVR-111L
DVR-112	DVR-112C	DVR-112D	DVR-112L
DVR-212	DVR-212D	DVR-212L	DVR-K04
DVR-K04L	DVR-K06	DVR-K11	DVR-K12AS
DVR-K12D	DVR-K13	DVR-K13AS	DVR-K14
DVR-K14L	DVR-K15	DVR-K16	DVR-K16A
DVR-K16F	DVR-K16L	DVR-K16M	DVR-K17
BD-RW BDR-209M	BD-RW BDR-US01	BD-RW BDR-XS05	BD-RW BDR-UD03
DVD-RW DVR-221L	BD-RW BDR-209MIO	BD-RW BDR-XD05	BD-RW BDR-XU03J
BD-RW BDR-XS06JL	BD-RW BDR-S08	BD-RW BDR-S09	BD-RW BDR-S11
BD-RW BDR-211M	BD-RW BDR-XD06U	BD-RW BDR-XD07U	BD-RW BDR-UD04

PLDS			
DVD A DH20A4P	DVD A DH22A9P	DVD+-RW DS-8A8SH	DVD-RW DH16ACSH
DVD+-RW DH-16AES	DVD+-RW DU-8A5LH	DVD-RW DU8A6SH	DVD-RW DS8A9SH
DVD-RW DH16AESH	DVD-RW DH16ABSH		

PLEXTOR			
BD-R PX-B950SA	CD-R PREMIUM	CD-R PX-230A	DVDR PX-755A
DVDR PX-760A	DVDR PX-800A	DVDR PX-810UF	DVDR PX-504A
DVDR PX-704A	DVDR PX-708A	DVDR PX-712A	DVDR PX-716A
DVDR PX-750A	DVDR PX-751A	PX-320A	PX-R412C
PX-R820T	PX-S2410T	PX-S88T	PX-W1210A
PX-W1210S	PX-W124TS	PX-W1610A	PX-W2410A
PX-W4012A	PX-W4012S	PX-W4220T	PX-W4824A
PX-W5224A	PX-W8220T	PX-W8432T	DVDR PX-880SA
DVDR PX-891SA			

POLAROID			
48X CD-RW DRIVE	BurnMAX52	BurnMAX52EX	BurnMAX52EX SO
BurnMAX52SO			

PROVIEW			
CD-R/RW 52X24X52			

Q-lity			
ECW-043			

QPS			
CRD-BP1500P	CRD-BPO1700P	QPSCRD-BP1600P	

QSI			
CDRW/DVD SBW242B	CDRW/DVD SBW242C	CDRWDVD SBW-246	CDRWDVD SBW-246I
DVD RW SDW-087	DVD RW SDW-087F	DVD RW SDW-087H	DVD RW SDW-087I
DVD RW SDW-087L	DVD RW SDW-089B	DVD RW TDW-081	DVD RW TDW-081I
DVD-RAM SDW-086K	SBW-081	SBW-161	SBW-241
SBW-242	SBW242U		

R-QUEST			
TRUECOPY40A			

RICOH			
DVD+RW MP5163AN	DVD+RW MP5240A	DVD+RW MP5308D	DVD+RW MP5316DA
DVD+RW MP5316DAD	DVD+RW MP5316DAG	DVD+RW RW8165	MC104S
MP5120	MP5125	MP5240	MP6200
MP6201	MP7040A	MP7040S	MP7060A
MP7060S	MP7063A	MP7080A	MP7083A
MP7120A	MP7122SE	MP7125A	MP7163A
MP7200A	MP7320A	MP7400A	MP8040S
MP8160	MP9060	MP9120	MP9200
RO1420C	RW104S	RW5120	RW5125
RW5240	RW7040A	RW7040S	RW7060A
RW7060S	RW7063A	RW7080A	RW7083A
RW7120A	RW7125A	RW7163A	RW7200A
RW7320A	RW7400A	RW8040A	RW8080A
RW8160	RW9060	RW9120	RW9200

RIDATA			
DVD DUAL 4XMax	DVD RW 4XMax	DVD RW 8XMax	DVD+RW DRIVE
DVD+RW/+R DRIVE			

SAF			
CD-R8020	CD-RW12432	CD-RW8220	

SAMSUNG			
CDDVDW SH-S223F	CDRW/DVD SM-352F	DVD R/RW SR-W04B	DVD-MULTI SRT03B
SM-304B	SM-308B	SM-308N	SM-348B
SM-352B	SW-207F	SW-216B	SW-240B
SW-252B	SW-408B		

SANYO			
CRD-BP1300	CRD-BP1400	CRD-BP1500	CRD-BP1500U
CRD-BP1600	CRD-BP1700	CRD-BP1700U	CRD-BP1800P
CRD-BP2	CRD-BP3	CRD-BP4	CRD-BP5
CRD-BP900	CRD-BPDV2	CRD-BPDV3	CRD-R800S
CRD-RW1	CRD-RW2	CRD-SBP15A	

SHARK			
CDRW1610IM			

Slimtype			
COMBI LSC-24081	COMBI LSC-24081S	COMBI LSC-24101	COMBI LSC-24121
COMBO LSC-24081	COMBO LSC-24081M	COMBO LSC-24081S	COMBO LSC-24101
COMBO LSC-24121	DVD A DS8A4S	DVD A DS8A5S	DVD+RW SDW-421S
DVDRW SDW-431S	DVDRW SOSW-852S	DVDRW SSM-8515S	XJ-SC241
XJ-SC241M	DVD A DU8A3S	eBAU108 6 L	eTAU108 1
DVD A DS8A9SH	DVD A DL8A4SH	DVD A DU8A6SH	

Smart & Friendly			
CD-RW4420J5			

SONY			
CD-RW CRX230ED	CD-RW CRX320E	CRX100E	CRX110E
CRX120E	CRX140E	CRX140S	CRX160E
CRX160S	CRX1611	CRX168E	CRX175A
CRX175A1	CRX175E2	CRX185E1	CRX185E3
CRX195E1	CRX195E4	CRX200E	CRX205E1
CRX210E1	CRX215E1	CRX216E	CRX217E
CRX220E1	CRX220E2	CRX225E	CRX230E
CRX230E5	CRX300E	CRX700E	CRX75L
CRX810E	CRX820E	CRX85A	CRX950E
CRXP-90MU	DRU-120A	DRU-500A	DRU-510A
DVD RW AW-G170A	DVD RW AW-G170S	DVD RW AW-G173A	DVD RW AW-G173S
DVD RW AW-G540A	DVD RW AW-G543A	DVD RW AW-G630A	DVD RW AW-G633A
DVD RW AW-G910A	DVD RW AW-G913A	DVD RW AW-Q170A	DVD RW AW-Q170S
DVD RW AW-Q173A	DVD RW AW-Q173S	DVD RW AW-Q540A	DVD RW AW-Q543A
DVD RW AW-Q630A	DVD RW AW-Q633A	DVD RW AW-Q910A	DVD RW AW-Q913A
DVD RW DRU-530A	DVD RW DW-U18A	DW-U10A	DW-U12A
DW-U14A	DW-U50A	MPD-AP20U	

TDK			
CDRW121032A	CDRW161040X	CDRW241040X	CDRW321040X
CDRW401240X	CDRW401248UEX	CDRW481248B	CDRW482448AID
CDRW482448B	CDRW5200B	CDRW5201B	CDRW8824T
DVDRW0404N	DVDRW1616EX	DVDRW1616N	DVDRW420N
DVDRW840	DVDRW880N	DVDRW882N	

TEAC			
BD-C26SS-A	BD-C26SS-AF	BD-C26SS-AS	CD-P520E
CD-R50S	CD-R55S	CD-R56S	CD-R58S
CD-W216E	CD-W224EA	CD-W224S-A	CD-W224SS-W
CD-W24E	CD-W28E	CD-W512E	CD-W512EB
CD-W512S	CD-W516EB	CD-W516EC	CD-W524E
CD-W540E	CD-W548E	CD-W54E	CD-W552E
CD-W552G	CD-W552GB	CD-W58E	DV-W18S-A
DV-W18S-AF	DV-W22E	DV-W24E	DV-W24EP
DV-W24ES	DV-W24EW	DV-W28E	DV-W28EA
DV-W28EAD	DV-W28EBF	DV-W28EC	DV-W28ECF
DV-W28ECS	DV-W28ECT	DV-W28ECTF	DV-W28ECW
DV-W28EP	DV-W28E-R	DV-W28E-RF	DV-W28E-RS
DV-W28EW	DV-W28S-A	DV-W28SL	DV-W28SLA
DV-W28SLC	DV-W28SLCF	DV-W28SLCT	DV-W28SLCTF
DV-W28SLCW	DV-W28S-R	DV-W28S-RF	DV-W28S-RS
DV-W28SS-R	DV-W28SS-RF	DV-W28SS-RS	DV-W28SS-V
DV-W28SS-VF	DV-W28SS-VS	DV-W28S-V	DV-W28S-VF
DV-W28S-VS	DV-W28S-W	DV-W28S-WF	DV-W28SS-W
DV-W28SS-WF	DV-W28U-V	DV-W28U-VF	DV-W5000E
DV-W5000S	DV-W50D	DV-W50E	DV-W516E
DV-W58D	DV-W58G-A	DW-224E	DW-224E-A
DW-224E-B	DW-224E-C	DW-224E-CN	DW-224E-R
DW-224E-V	DW-224E-VN	DW-224SL-R	DW-224SS-W
DW-224S-V	DW-28E	DW-548D	DW-552G
DW-552GA	DV-W5600S		

TOSHIBA			
CD/DVDW SD-R5372	CD/DVDW SD-R6472	CD-R/RW SR-M8102	CD-R/RW SRM8202C
CDW/DVD SD-R1612	CDW/DVD SDR1712C	CDW/DVD SD-R2612	CDW/DVD SDR2612C
DVD/HDW SD-L902A	DVD/HDW SD-L912A	DVD-ROM SDR2512N	DVDW/HD TS-L802A
IPC5025A	ODD-DVD SDR1412N	ODD-DVD SDR1412T	ODD-DVD SDR1412T
ODD-DVD SD-R5272	ODD-DVD SD-R6352	ODD-DVD SD-R6372	SD-R1002
SD-R1102	SD-R1202	SDR1202F	SDR1202N
SD-R1312	SD-R2002	SD-R2102	SD-R2212
SD-R2312	SD-R2412	SD-R2512	SD-R2512
SD-R5002	SD-R5112	SD-R5112	SDR5112N
SDR5112N	SD-R6012	SD-R6112	SD-R6112
SDR6112N	SDR6112N	SD-R9012	SD-R9012
SR-C8002	SR-C8102		

TRAXDATA			
CDRW4424 PLUS	CDRW4432 PLUS	CDRW522452plus	CDRW-5224E
CDRW-5224E SO			

TSSTcorp			
BDDVDW SN-506AB	CD/DVDW TS-H552A	CD/DVDW TS-H652D	CD/DVDW TS-H653A
CD/DVDW TS-L532A	CD/DVDW TS-L532R	CD/DVDW TS-L532S	CD/DVDW TS-L632D
CD/DVDW TS-U632A	CD/DVDW TSU632AN	CD/DVDW TS-U632R	CDDVDW SH-S243D
CDDVDW SN-208BB	CDDVDW TS-H653F	CDDVDW TS-L633C	CD-R/RW TS-H292A
CD-R/RW TS-H292C	CDRW/DVD TSL462D	CDW/DVD TS-H492A	CDW/DVD TSH492AN
CDW/DVD TS-H492C	CDW/DVD TSH492CN	CDW/DVD TS-L462A	CDW/DVD TS-L462C
CDW/DVD TSL462CN	CDW/DVD TS-L462D	DVDWBD SH-B123L	DVD-RW SH-216AB
DVD+-RW TS-H653A	DVD+-RW TS-H653F	DVD+-RW TS-L633C	DVD+-RW TS-L633J
DVD-RW SH-216BB	CDDVDW SN-208DN	DVD+-RW SH-216DB	CDDVDW SH-224DB
CDDVDW SN-208FB	CDDVDW SU-208FB	BDDVDW SN-506BB	CDDVDW SN-208DB
CDDVDW SH-224BB	CDDVDW SU-208DB	CDDVDW SU-208CB	DVD+-RW SU-208FB
CDDVDW SN-S083C	CDDVDW SE-208DB	CDDVDW TS-H653R	

VERBATIM			
241040AL	321040AL	401248AL	481248AL
482448AL	522452AL		

WAITEC			
MEGALUS	SAURUS	SFINX16	SHUTTLE
STORM32	STORM40	WT2444EI	WT3244EI

WDC			
WDC12432SS			

WPI			
CDRW-4424			

YAMAHA			
CDR200	CDR400	CRW2100E	CRW2100S
CRW2200E	CRW2200S	CRW2216E	CRW3200E
CRW3200S	CRW4260	CRW4416E	CRW4416S
CRW6416S	CRW-70	CRW8424E	CRW8424S
CRW8824E	CRW8824S	CRW-F1E	CRW-F1S

**【その他の注意事項】**

※対応ドライブとして記述されたドライブ型番でも、接続I/Fが変換(例: ATAPIからUSB, IEEE1394, SCSIなど)されたり、ATA拡張カードに接続されたドライブでは正常に動作できない場合があります。

B's DVDビデオ 3 パージョン変更履歴			
Ver No.	対応(追加)した		変更内容
	ドライブメーカー名	ドライブ型番	
3.01	Slimtype	DVD A DL8A4SH	
	TSSTcorp	CDDVDW SN-S083C	
3.02	PIONEER	BD-RW BDR-S11	
	TSSTcorp	CDDVDW SE-208DB	
3.03	PLDS	DVD-RW DH16AESH	
3.04	PLDS	DVD-RW DH16ABSH	
3.05	TSSTcorp	CDDVDW TS-H653R	
3.06	PIONEER	BD-RW BDR-211M	スライドショーのプレビュー表示が正常に行えない場合があったので修正しました。
3.07	HL-DT-ST	BD-RE BU40N	
3.08	PIONEER	BD-RW BDR-XD06U	
3.09	hp	BD-RE BH20L	
	hp	BD-RE BH20N	
3.10	Slimtype	DVD A DU8A6SH	特定のMP4ファイルが正常に登録できない場合があったので修正しました。
3.11	PIONEER	BD-RW BDR-XD07U	
3.12	PIONEER	BD-RW BDR-UD04	特定のコーデックがインストールされている環境下でMP4ファイルを登録するとランタイムエラーが発生する場合があったので修正しました。

対応プロダクト数:1627